



METAL ROOF: THREE COURSE FABRIC REINFORCED

Finger Flashed Fabric Cut Detail For Wrap Around Penetration Base



Cut / Slice the Fabric into "Fingers" About Half as Deep as the Fabric Width and Wrap Around the Entire Base of the Pipe / Penetration.



1. Apply a layer of AWS fabric bond coating extending from 6" up the penetration and extending 6" on to the existing metal roof.
2. Embed "finger flashed" (see Picture above) 6" AWS polyester fabric into wet fabric bond coating on pipe and out on to existing metal roof.
3. Apply a layer of AWS fabric bond coating extending from 6" up the penetration and extends 6" on to the existing metal roof encapsulating the polyester fabric.

NOTE: Contact American WeatherStar with any questions.



800.771.6643

AMERICANWEATHERSTAR.COM

PENETRATION RESTORATION DETAIL

See specific application guideline for suitable AWS fabric bond coating.

NOTE: This detail is provided to show a generally recommended procedure for dealing with the condition shown. It will not and cannot provide a specific solution for every condition likely to be encountered in field application. Where field conditions differ, the use of applicable portions of the detail shown or its adaptation by an experienced and conscientious applicator should result in a quality project.

LEGEND



FABRIC BOND COATING



POLYESTER FABRIC

REVISION DATE: 12/28/2015

SCALE: NTS