



Roof Surface/System Cross Reference Chart
EPDM

SYSTEM	WARRANTY LENGTH	PRIMER	GAL/SQ	BASE COAT	GAL/SQ	INTERMEDIATE COAT	GAL/SQ	TOP COAT	GAL/SQ	TOTAL DFT	
Acrylic	10 years	Fabric Bond 930*	.5	Acrylic 211	1.5	—	—	Acrylic 211	1.5	25	
	15 years	Fabric Bond 930*	.5	Acrylic 211	1.25	Acrylic 211	1.25	Acrylic 211	1.25	30	
Envir-O-Sil (High-Solids Silicone)	10 years	Fabric Bond 930*	.5	High-Solids Silicone 412	.75	—	—	High-Solids Silicone 412	.75	20	
	15 years	Fabric Bond 930*	.5	High-Solids Silicone 412	1.1	—	—	High-Solids Silicone 412	1.1	30	
	20 years	Fabric Bond 930*	.5	High-Solids Silicone 412	1.25	—	—	High-Solids Silicone 412	1.25	35	
Silicone (Standard-Solids Silicone)	10 years	Fabric Bond 930*	.5	Silicone 410	1	—	—	Silicone 410	1	20	
	15 years	Fabric Bond 930*	.5	Silicone 410	1.5	—	—	Silicone 410	1.5	30	
	20 years	Fabric Bond 930*	.5	Silicone 410	1.75	—	—	Silicone 410	1.75	35	
Urethane	10 years	—	—	Aromatic Urethane 520	1.25	—	—	Aromatic Urethane 520	1.25	25	
Urethane (Hybrid)	10 years	—	—	Aromatic Urethane 520	1	—	—	Aliphatic Urethane 510	1.5	25	
	15 Years	—	—	Aromatic Urethane 520	1.5	—	—	Aliphatic Urethane 510	1.5	30	
	20 Years	—	—	Aromatic Urethane 520	1.25	Aromatic Urethane 520	1.25	Aliphatic Urethane 510	1.5	40	
Ure-A-Sil	12 years	—	—	Aromatic Urethane 520	1	—	—	Silicone 410	1.5	25	
								High-Solids Silicone 412	1.1		
	15 years	—	—	Aromatic Urethane 520	1.5	—	—	Silicone 410	1.5	30	
								High-Solids Silicone 412	1.1		
	20 years	—	—	Aromatic Urethane 520	1.25	—	Silicone 410	1.25	Silicone 410	1.25	35
									High-Solids Silicone 412	1.8	
Ure-A-Sil California	12 years	—	—	Aromatic Urethane 512-CA	1	—	—	High-Solids Silicone 412	1.1	25	
	15 years	—	—	Aromatic Urethane 512-CA	1.5	—	—	High-Solids Silicone 412	1.1	30	
	20 years	—	—	Aromatic Urethane 512-CA	1.25	High-Solids Silicone 412	.9	High-Solids Silicone 412	.9	35	

Refer to application guidelines for detailed installation instructions. Adhesion tests are required for all roof restoration projects.

* Depending on the condition of the existing roof system, a primer may not be necessary. Contact American WeatherStar technical services for more information.

DFT = Dry Film Thickness